

## **MOTOROLA**

# MD450 Series

Digital 2.4GHz Expandable Cordless Telephone System

User's Guide >

#### Congratulations on your purchase of a Motorola product!

Product registration is an important step. Registering helps us facilitate warranty service and permits us to contact you if your Motorola product requires an update or other service.

To register your product online, visit:

www.motorola.com/warranty/cordless


Please retain your original dated sales receipt for your records. For warranty service of your Motorola product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

For a large-print version of this guide, or for productrelated questions, please call:

> 1-800-353-2729 in the USA 1-888-390-6456 TTY (Text Telephone) On the Web:

> > www.motorola.com/cordless

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. © Motorola, Inc. 2003



#### FCC and Interference Information

This equipment complies with Parts 15 and 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachments (ACTA).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

#### **Notification of the Local Telephone Company**

On the bottom of this equipment is a label that contains, among other information, a product identifier in the form US:AAAEQ##TXXXX. You must, upon request, provide this information to your telephone company.

The digits represented by ## in the product identifier indicate the Ringer Equivalency Number (REN) for this equipment. The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, contact your local telephone company.

#### Notes:

- This equipment may not be used on coin service provided by the telephone company.
- Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this cordless phone does not disable your alarm equipment. If you have questions

- about what will disable alarm equipment, consult your telephone company or a qualified installer.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C/RJ11W or RJ14C/RJ14W).

#### Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practical and the circumstances warrant such action, the telephone company may temporarily disconnect service immediately. In case of such temporary discontinuance, the telephone company must:

- 1. Promptly notify you of such temporary discontinuance;
- 2. Afford you the opportunity to correct the situation;
- Inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

#### Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference with one or more of the following measures:

Reorient or relocate the receiving antenna (that is, the antenna for the radio or television that is "receiving" the interference).

Reorient or relocate and increase the separation between the telecommunications equipment and the receiving antenna.

Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How to Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

The FCC requires this product to be serviced only by Motorola or its authorized service agents. Changes or modifications not expressly approved by Motorola could void not only the user's authority to operate the equipment, but also the limited warranty.

#### **Hearing Aid Compatibility**

This telephone system meets the FCC standards for hearing aid compatibility.

### Important Safety Instructions

Follow these safety precautions when using your cordless phone to reduce the risk of fire, electric shock, and injury to persons or property:

- Keep all slits and openings of the phone unblocked. Do not set the phone on a heating register or over a radiator. Ensure that proper ventilation is provided at the installation site.
- 2. Do not use while wet or while standing in water.
- 3. Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool).
- Do not allow anything to rest on the power cord. Place the power cord so that it will not be walked on.
- Never insert objects of any kind into the product slits as that may result in fire or shock.
- Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- Do not disassemble this product. If service or repair work is required, contact the Motorola address found in the back of this user's guide.
- 8. Do not overload wall outlets and extension cords.
- 9. Avoid using during an electrical storm. Use a surge protector to protect the equipment.
- Do not use this cordless phone to report a gas leak, especially if you are in the vicinity of the gas line.

**Caution:** To reduce the risk of fire, use only No. 26 AWG or larger UL Listed or CSA Certified Telecommunication Line Cord.

#### Unplug this cordless phone immediately from an outlet if:

- The power cord or plug is damaged or frayed.
- · Liquid has been spilled into the product.
- The product has been exposed to rain or water. Do not retrieve
  the handset or base until after you have unplugged the power
  and phone from the wall. Then retrieve the unit by the
  unplugged cords.
- The product has been dropped or the cabinet has been damaged.
- The product exhibits a distinct change in performance.

#### Installation Guidelines

- Read and understand all instructions and save them for future reference.
- 2. Follow all warnings and instructions marked on the product.
- 3. Do not install this product near a bath tub, sink, or shower.
- 4. Operate this phone using only the power source that is indicated on the marking label. If you are unsure of the power supply to your home, consult with your dealer or local power company.
- 5. Do not place this product on an unstable cart, stand, or table. This product may fall, causing serious damage to the product.
- Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work to restore the product to normal operation.
- 7. Clean this product with a soft, damp cloth. Do not use chemicals or cleaning agents to clean this phone.

- 8. Use only the power supply that came with this unit. Using other power supplies may damage the unit.
- Because cordless phones operate on electricity, you should have at least one phone in your home that is not cordless in case the power in your home goes out.
- To avoid interference to nearby appliances, do not place the base of the cordless phone on or near a TV, microwave oven, or VCR.

**Caution:** To maintain compliance with the FCC's RF exposure guidelines, place the base unit at least 20 cm from nearby persons.

#### **Battery Safety Instructions**

- Do not burn, disassemble, mutilate, or puncture the battery. The battery contains toxic materials that could be released, resulting in injury.
- Caution: There is a risk of explosion if you replace the battery with an incorrect battery type. Use only the battery that came with your phone or an authorized replacement recommended by the manufacturer.
- · Keep batteries out of the reach of children.
- · Remove batteries if storing over 30 days.
- Do not dispose of batteries in fire, which could result in explosion.
- The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type.
   Contact your local recycling center for proper disposal methods.

### **Contents**

Handset Controls	2
FCC and Interference Information	3
Important Safety Instructions	
Getting Started	
Powering the Base Station	12
Setting Up the Charging Bases	
Installing Batteries in the Handsets	13
Charging the Handsets	13
Phone Line Connection	14
Wall Mounting the Base Station	14
Removing the Base Station and Wall Mount	16
Removing the Base Station from the Wall Mount	17
Using the Handset Display	17
Using the Soft Keys	17
Using the Navigation Key	18
Setting Up Your Phone	19
Registering an Expansion Handset	19
Personalizing Your Handset	19
Setting the Ring Tone and Ring Volume	20
Turning the Key Beeps ON or OFF	22
Naming a Handset	23
Entering Text on the Handset	
Storing Area Codes for Caller ID	24
Setting the Date and Time	
Setting the Language	27
Setting Touch Tone or Pulse Dialing	
Using the Handset	
Making a Call	28
Adjusting the Volume During a Call	∠ŏ
Making a Call Using the Speakerphone	∠ყ
Adjusting the Speakerphone Volume Switching Between the Handset and	∠9
Speakerphone	20
Muting a Call	∠ა
widing a Dail	

Putting a Call on Hold	. 30
Redialing a Number	. 30
Finding a Lost or Misplaced Handset	. 31
Saving a Number in the Phonebook	. 31
Sorting the Phonebook	. 33
Calling a Number from the Phonebook	
Editing a Phonebook Entry	
Deleting a Phonebook Entry	
Inserting Pauses in a Number	. 36
Using Automated Dialing	. 36
Using Caller ID	. 37
Reviewing the List of Caller ID Calls	. 37
Store a Caller ID Number in the Phonebook	. 38
Deleting Caller ID Calls	. 39
Multihandset Functions	
Conference Calling	. 41
Using the Intercom	
Intercom Setup	. 42
Handset to Handset Intercom	
Transferring a Call from One Handset to Another	
Unannounced Transfer	
Announced Transfer	
Using the Handset as a Walkie-Talkie	
Monitoring a Room	. 46
Deregistering All Handsets	. 47
Motorola Limited Warranty for the	
United States and Canada	. 48

## **Getting Started**

To set up your Motorola digital cordless phone system:

- Install optional backup batteries in the base station and plug into a power outlet (page 12).
- 2. Plug in charging bases for expansion handsets (page 13).
- 3. Install batteries in handsets (page 13).
- Charge handset batteries (page 13).
   A rechargeable NiCd battery powers each handset. Charge the battery for about 12 hours before initial use.
- Connect the base station to the phone line (page 14).
- Register expansion handsets to the base station (page 19).
  - Handsets that come with your phone system are already registered to the base.
- 7. Set the ring tone, date, time, and other features of your phone (page 20).

#### Place the Base Station:

- Away from electrical appliances such as a TV, personal computer, or another cordless phone.
- In a high and central location with no obstructions, such as walls.


If you hear noise while using the handset near a microwave or another cordless phone's base unit, move away from the microwave or base unit and closer to your handset's base station.

## **Powering the Base Station**

**Important:** Before installing or handling batteries, read the Battery Safety Instructions on page 8.

The base station uses 4 AAA alkaline batteries for optional backup power (batteries are included with some models). To install the batteries in the base station:

- 1. With the bottom of the base facing you, press the cover latch with a screwdriver to lift and remove the battery cover.
- 2. Insert 4 AAA alkaline batteries into the battery compartment.



- 3. To replace the cover, insert the tabs of the cover into the slots on the base station and press down until the cover clicks into place.
- Plug the power cord into the back of the base station and into an outlet.



## **Setting Up the Charging Bases**

If you have expansion handsets, they do not need to be plugged into a phone line. Simply plug the power cord into the back of the charging base and into an outlet wherever you want to place the handset.

## Installing Batteries in the Handsets

**Important:** Before installing or handling batteries,

- Important: Before installing or handling batteries, read the Battery Safety Instructions on page 8.

  1. Remove the battery cover by pressing on the recess and sliding down and off the handset.

  2. Plug the connector into the receptacle.

  39 0.0004 1oneh9(tte0.4()]e retter)-1423(w)yfneh9(ttem(e hat.))

For the initial charge, charge the battery for at least 12 hours.



#### **Phone Line Connection**

Do not connect the base station to the phone line until the handset is fully charged.

## **Wall Mounting the Base Station**


The base station can be mounted on a wall instead of placed on a flat surface such as a table or desk.

- Remove the twist-tie from the phone cord. Do not unfold the cord.
- Untuck both ends of the cord.


3. Hold the folded cord at the center and insert it into the back of the wall mount bracket.




4. Plug the phone cord into the phone jack on the wall.



Hang the wall mount bracket on the phone wall plate.



Plug the other end of the phone cord into the back of the base station. Plug the power cord into a power outlet if it is not already plugged in.



8. Insert the four tabs on the wall mount into the four slots on the back of the base station and push until it snaps into place.

# Removing the Base Station and Wall Mount


Push up on the wall mount to dislodge it and the base station from the phone wall plate.

## Removing the Base Station from the Wall Mount

Press the release tab located above the bottom screw hole on the wall mount.

## **Using the Handset Display**

When the handset is not in use, the display shows the **standby screen**.




**Note:** Caller ID information is supplied only if you subscribe to caller ID service from your local phone company.

When the handset speakerphone is on, **◄** appears on the display.

#### **Using the Soft Keys**

The 2 soft keys are used to select the functions listed above these keys on the display. The functions change as you move from one screen to the next. In this guide, soft key functions are shown as the function name followed by , for example, CHANGE ().



## **Setting Up Your Phone**

## Registering an Expansion Handset

You can have up to 4 handsets registered to a base station. If you try to register a 5th handset, Unable to Register displays.

Handsets that come with your MD450 Series phone system are already registered. You only need to register handsets if you buy expansion handsets to add to your phone system.

To register a new expansion handset that has never been registered to a base station before:

#### Action

- Press 0K ( ).
- 2 Within 5 seconds of step 1, press and hold PAGE on the base station for at least 6 seconds or until you hear a long beep and see the handset name, for example, Handset(2).
- 3 Press 0K ( ) to return to the standby screen.

## **Personalizing Your Handset**

You can personalize each handset by setting unique ring tones, adjusting the ring tone volume for day and night time, and assigning a name so you can distinguish one handset from another.

#### Setting the Ring Tone and Ring Volume

Your can set a ring tone for incoming calls from numbers that are stored in the phonebook, and a different ring tone for other incoming calls. The phonebook ring tone works only if you subscribe to caller ID service.

- 1 Press MENU (CD).
- 2 Scroll to Ringer and press SELECT ( ).
- 3 The Day Volume displays. This is the ringer volume from 6 am to 9 pm. Press CHANGE () to scroll through the settings (off, low, medium, high). Each volume level plays as you press CHANGE (). Stop at the volume level you want to set.
- 4 Scroll down ((\*\*)) to advance to the Night Volume. This is the ringer volume from 9 pm to 6 am. Press CHANGE ((\*\*)) to scroll through the settings. Each volume level plays as you press CHANGE ((\*\*)). Stop at the volume level you want to set.
- 5 Scroll down (③) to advance to the Ring Tone. This is the ring sound for incoming calls.
- 6 Press CHANGE ( ) to scroll through the ring tones. Each tone plays as you select CHANGE ( ). Stop at the ring tone you want to set.

- 7 Scroll down (②) to advance to the Phonebook Tone. This is the sound for incoming calls from numbers stored in your phonebook. You must subscribe to caller ID service for this ring tone to work.
- 8 Press CHANGE ( ) to scroll through the phonebook tones. Each tone plays as you select CHANGE ( ). Stop at the phonebook tone you want to set.
- 9 Press DONE (-).
- 10 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

#### **Turning the Key Beeps ON or OFF**

You can turn ON or OFF the key beeps on the handsets.

#### **Action**

- 1 Press MENU ( ).
- 2 Scroll (🔘) to Ringer and press SELECT (😑).
- 3 Scroll (☼) to Key Beeps and press SELECT (⇐).
- 4 Press CHANGE ( ) to scroll through the selection. When your choice of ON, OFF, or LINKED to RINGER displays, press SELECT ( ).

**Note:** When set to LINKED to RINGER, key beeps are ON when the ringer is set to ON, and off when the ringer is set to OFF on the handset.

#### Naming a Handset

When you register a handset, it is assigned a default name of Handset(x), where x can be 1, 2, 3, or 4. You can change the name to something more useful, for example a location (Kitchen) or someone's name (Susan). Naming a handset makes it easy to select the handset from a list (for example, to intercom another handset).

If you name a handset, the handset number remains part of the name, for example, Kitchen(2).

- 1 Press MENU (CD).
- 2 Scroll to Name handset and press SELECT ( ).
- 3 Use the keypad to enter the handset name (up to12 characters). The flashing underline shows the input cursor position. Press DELETE ( ) to backspace and erase characters to the left of the input cursor. See page 24 for information on how to enter text.
- 4 Press DONE (○□).
- 5 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

#### **Entering Text on the Handset**

Press each button on the handset the indicated number of times to enter text, numbers, and other characters. For example, to enter R, press the 7 button 3 times.

	Number of Presses				
Button	1	2	3	4	5
1	space	_	*	!	1
2	Α	В	С	(	2
3	D	Е	F	)	3
4	G	Н	I	#	4
5	J	K	L	/	5
6	М	N	0		6
7	Р	Q	R	S	7
8	Т	U	V	?	8
9	W	Х	Υ	Z	9

## **Storing Area Codes for Caller ID**

**Note:** This section applies only if you subscribe to caller ID service from your local phone company.

You can store up to 5 area codes to make it easy to dial numbers from your list of caller ID calls. Each area code can be:

- 7-digit format
   You do not have to dial the area code to call numbers
   in this area code.
- 10-digit format
   You have to dial the 3-digit area code + 7-digit phone
   number to call numbers in this area code.

 11-digit format
 You have to dial the 1 + 3-digit area code + 7-digit phone number to call numbers in this area code.

For example, if you store 954 in 10-digit format, when you receive a call from that area code, the phone number is stored in your call list with all 10 digits. The number will then be in the correct format for you to dial directly from the call list without any reformatting.

- Press MENU (
  ).
- 2 Scroll to Loc arrea code and press SELECT ( ).
- 3 Enter the first area code.
- 4 Press FORMAT ( ) to scroll through the formats. Stop at the format you want to set for the area code, then scroll down ( ) to move to the next area code.
- 5 Repeat steps 3 and 4 to store up to 4 more area codes. When you are finished, press DONE (<</p>
- 6 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

## **Setting the Date and Time**

#### **Action**

- 1 Press MENU (CD).
- 2 Scroll to Date/Time and press SELECT ( ).
- 3 Enter the time (2 digits are required for the hour and 2 digits for the minutes, so use a leading 0 for 1-digit values).
- 4 Press AM/PM ( ) to switch between am and pm.

**Note:** This applies only if using a 12-hour clock.

- 5 Scroll down ((2)) to move the next field.
- 6 Press CHANGE ( ) to change the time format (12- or 24-hour clock). Scroll down ( ) to move to the next field.
- 7 Press CHANGE ( ) to select date format (MM/DD or DD/MM).
- 8 Scroll down (3) to move the next field.
- 9 Enter the current date.
- 10 Press DONE (CD).
- 11 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

## Setting the Language

#### **Action**

- 1 Press MENU (CD).
- Scroll to Language and press SELECT (
- 3 Press ② until ▶ points to the language you want to set.
- 4 Press DONE (○□).
- 5 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

## Setting Touch Tone or Pulse Dialing

Your phone is set to touch tone dialing. Do not change this setting unless touch tone service is not available in your area.

- 1 Press MENU (👄).
- 2 Scroll to Tone/Pulse.
- 3 Press (5) or CHANGE ( 5) to switch between Tone and Pulse.
- 4 Press DONE (○ ).
- 5 Press EXIT ( ) to return to the standby screen, or to scroll to a different menu option.

## **Using the Handset**

## Making a Call

Press ON. When you hear the dial tone, dial the number.

or


Enter the phone number, then press ON. This lets you see the phone number on the display before the number is dialed.

During a call, a timer on the display shows the amount of time on the call.

When you are finished talking, press OFF to hang up. Press ON or Handsfree to answer using the speakerphone.

If you have call waiting service, press ON to answer the second call.

## Adjusting the Volume During a Call



When you are not on a call, use the volume keys to change the day (6 am–9 pm) or night (9 pm–6 am) ringer volume. The time of day as set on the phone determines whether you are adjusting the day or night volume. To set the time, see page 26.

## Making a Call Using the Speakerphone

Press Handsfree and dial the number. For optimal speakerphone sound quality, make sure the belt clip is on. This raises the handset up so it is not lying flat (the speakerphone is on the back of the handset).

When the speakerphone on the handset is on, • mappears on the display.

When you are finished talking, press OFF to hang up and turn the speakerphone off.

**Note:** Pressing Handsfree while in the caller ID list, redial list, or phonebook turns the speakerphone on and dials the number.

Press Handsfree.

If you have call waiting service, press ON to answer the second call.

## Adjusting the Speakerphone Volume

Press the volume up or volume down key (see page 28).

## Switching Between the Handset and Speakerphone

Press Handsfree to toggle between handset and speakerphone.

## **Muting a Call**

Press MUTE ( ). To unmute the call, press UNMUTE ( ).

## **Putting a Call on Hold**

Press HOLD ( ).

To return to the call, press UNHOLD ( ) or ON. When a call is on hold, you can use the intercom features (see page 43).

## Redialing a Number

To redial the most recently dialed number:

#### **Action**

- 1 Press ON.
- 2 Press Redial.

To redial one of the last 5 numbers you dialed:

#### Action

- 1 Press Redial.
- 2 Press © until ▶ points to the number you want to redial.
  - 3 Press Dial ( ) or ON or Handsfree.

If a number in the redial list matches a number in your phonebook, the phonebook name and number display in the redial list instead of just the phone number.

## Finding a Lost or Misplaced Handset

Press PAGE on the base station.

All handsets registered to the base station will start beeping.

Press Off, EXIT ( ), or ŪK ( ) on a handset to stop paging that handset, or press PAGE on the base station to stop paging all handsets.

## Saving a Number in the Phonebook

Storing numbers in the phonebook makes it easy to dial numbers you call frequently. You can enter numbers directly into the phonebook or add them from the caller ID or redial list.

Each handset has its own phonebook. The phonebook can hold 50 names and numbers.

- 1 Press PHONEBK ( ).
- 2 Scroll to (New Entry) and press SELECT ((=)).
- 3 Enter the name (up to 12 characters). Press DELETE ( ) to backspace and erase characters to the left of the blinking cursor. See page 24 for information on entering text.
- 4 Scroll down (🗘).
- 5 Enter the phone number (up to 24 digits). Press DELETE ( ) to backspace and erase characters to the left of the blinking cursor.
- 6 Press DONE ( ).

To store a recently called number in the phonebook:

#### **Action**

- 1 Press Redial. The display shows the last 5 numbers you dialed, with the most recent number at the top.
- 2 Press ⑤ until ▶ points to the number you want to save.
- 3 Press STORE ( ).
- 4 Enter the name (up to 12 characters). Press DELETE ( ) to backspace and erase characters to the left of the blinking cursor. See page 24 for information on entering text.
- 5 Scroll down (©).
- 6 The phone number displays in the Number: field. To modify the number, press DELETE ( ) to backspace and erase characters to the left of the blinking cursor.
- 7 When the phone number is correct as you want to store it, press DONE ( ).

**Note:** You can also store a number in the phonebook from the caller ID list (see page 38).

## **Sorting the Phonebook**

The private phonebook can be sorted alphabetically and independently in each handset. Once sorted, a phone book cannot be unsorted or reset to its previous list order.

	Action
1	Press PHONEBK ( ) and scroll ( ) to any phonebook entry.
2	Select OPTIONS.
3	Scroll down (۞) to Sort Phonebk.
4	Press SELECT. The handset displays "Alphabetically sont phonebk?"
5	Select YES or NO.
6	Press OFF to return to the standby screen.

# Calling a Number from the Phonebook

#### Action

- 1 Press PHONEBK ( ).
- 2 Press ⑤ until ▶ points to the entry you want to call.

**Note:** You can also search numerically by pressing the number(s) of the phone entry that you want to dial.

3 Press ON or Handsfree.

**Note:** To perform a speed dial, press PHONEBK (C), the location number, then press ON.

## **Editing a Phonebook Entry**

When editing a phonebook entry, you can change uppercase letters to lowercase letters.

- 1 Press PHONEBK ( ).
- 2 Press ⑤ until ▶ points to the entry you want to edit.
- 3 Press OPTIONS ( ).
- 4 Scroll to Edit and press SELECT ( ).

#### Action

5 To modify the name, press DELETE ( ) to backspace and erase characters to the left of the blinking cursor. See page 24 for information on entering text.

**Note:** The first letter of the entry is an uppercase letter. To change the entry from uppercase to lowercase, press \*. A flashing square indicates that you are in the uppercase text entry mode. A flashing \_ indicates that you are in the lowercase text entry mode.

- 6 Scroll down (③) to move to the phone number field.
- 7 Modify the number.
- 8 Press DONE ( ).

# **Deleting a Phonebook Entry**

## **Action**

- 1 Press PHONEBK ( ).
- 2 Press © until > points to the entry you want to delete.
- 3 Press OPTIONS (CD).
- 4 Scroll to Delete and press SELECT ( ).

# **Inserting Pauses in a Number**

At the position where you want to insert a pause, press # twice and then P displays. When you call a number with a pause, the phone waits 3 seconds before transmitting the next digits in the dialing sequence. This is useful, for example, when you have to dial 9 to get a dial tone or for going into a voicemail system.

# **Using Automated Dialing**

You can retrieve previously entered information from the phone book (such as a PIN or credit card number) during a phone call without have to re-enter additional numbers.

- 1 While on a call, press ② until ▶ points to the entry that you want to recall.
- 2 Press DIAL ( ).
- 3 Repeat steps 1 and 2 as many times as necessary to complete your transaction.

**Note:** This function is useful when using automated response systems. For example, you could access your bank account number by dialing the bank's phone number, entering your account number (using automated dialing), and PIN (using automated dialing). Then, you can enter your most frequently used prompt, for example, balance inquiry.

# **Using Caller ID**

**Note:** You must subscribe to caller ID service from your local telephone company to use the caller ID features of your phone.

If you subscribe to caller ID service, the caller's name and/or number are displayed when you receive an incoming call. If no caller ID information was sent from the phone company, or you do not subscribe to caller ID service, the display shows Incoming Call.

## Reviewing the List of Caller ID Calls

The handset can hold up to 40 caller ID records.

## **Action**

- 1 Press © to enter the recent calls list. The most recent call is listed first.
- 2 Press © to review more calls.
- 3 To call the number, press ON or Handsfree.

To reformat the number before you call it, press FORMAT () until the correct format displays. For example, if a number you want to call is stored with the area code (10 digits), but you do not use the area

code to call this number, press FORMAT () until the number appears without the area code (7 digits). For information on dialing formats, see page 24.

#### Store a Caller ID Number in the Phonebook

#### Action

- 1 From the caller ID list, press OPTIONS (CD).
- 2 Scroll to STORE and press SELECT ( ).
- 3 The caller's name displays in the Name: field. You can modify the name before storing it.
- 4 When the name is correct as you want to store it, press © to scroll down.
- 5 The caller's phone number displays in the Number: field. You can modify the number before storing it.
- 6 Press FORMAT ( ) to change the dialing format of the number (7-digit, 10-digit, or 11-digit).
- 7 When number is correct as you want to store it, press DONE (<</p>

**Note:** To modify the name or number before storing it, press DELETE ( ) to backspace and erase characters to the left of the blinking cursor. Then use the keypad to enter the name or number. See page 24 for information on entering text.

## **Deleting Caller ID Calls**

## **Action**

- 1 From the caller ID list, press OPTIONS ( ).
- 2 Scroll to Delete (to delete the current caller ID entry) or Delete All (to delete all caller ID calls) and press SELECT ().

**Note:** If deleting all calls, press YES ( ) at the Delete All? prompt.

3 Press BACK ( ) to return to the caller ID list.

# Multihandset Functions

The following multihandset functions require at least 2 (up to 4) handsets registered to the base station.

You can expand your phone system by adding Motorola MD Series expansion cordless handsets (up to a total of 4 handsets). Expansion handsets do not require connection to a phone line. You can place the handset and its charging base anywhere a standard electrical outlet is available.

With multiple handsets, you can:

- Conference call
- Talk handset to handset on the intercom
- Set up handsets to automatically answer intercom calls
- Transfer calls form one handset to another
- · Monitor a room
- Use 2 handsets as walkie-talkies

To order expansion handsets, call:

1-800-353-2729 USA 1-888-390-6456 TTY (Text Telephone) On the Web:

www.motorola.com/cordless

# **Conference Calling**

If one handset is already on a call, the display on other handsets registered to the same base station shows Line in use.

Once a second handset is added to the call, the displays on all handsets shows On conference. A maximum of 2 handsets can be on a conference call at the same time.

- To connect a second handset to a call, press ON or Handsfree on the second handset.
- 2 To disconnect from the conference call, press OFF on either or both handsets.

# **Using the Intercom**

## Intercom Setup

You can set up a handset so it automatically answers an intercom page after 1 or 3 rings. All handsets are set to No Auto Answer at the factory. Perform the following procedure on each handset to change this setting.

- 1 Press MENU(CD).
- 2 Scroll to Intercom Setup and press SELECT ( ).
- 3 Scroll to one of the answering options and press SELECT ( ):
  - No Auto Answer the handset will not automatically answer an intercom page. After 1 Ring or After 3 Rings the handset will automatically answer and turn on the speakerphone after 1 or 3 rings.
- 4 Press SELECT ( ).
- 5 Press EXIT( ) to return to the standby screen, or to scroll to a different menu option.

#### Handset to Handset Intercom

## **Action**

- Press Intercom.
- 2 From the list of handsets, press © until ▶ points to the handset you want to page, or to Select. All to page all handsets.

**Note:** If there are only 2 handsets registered to the base, pressing the Intercom button will automatically page the other handset.

- 3 Press PAGE (CD).
- 4 To answer the page, press OK (). The first handset to respond is connected.

If no one answers the page after 2 minutes, or if the person you are paging presses EXIT ( ) or OFF, No Answer displays on your handset and paging stops.

- 5 When someone answers the page, talk into the handset.
- 6 To end the intercom session, press OFF.

To turn the speakerphone on or off, press Handsfree. To mute or unmute the sound, press MUTE ( ) or UNMUTE ( ).

# Transferring a Call from One Handset to Another

#### **Unannounced Transfer**

## **Action**

- 1 Press HOLD ( ).
- 2 Press Intercom.
- 3 Scroll to the handset you want to transfer the call to and press PAGE ().

**Note:** If there are only 2 handsets registered to the base, pressing the Intercom button will automatically page the other handset.

4 Press OFF to hang up. The call is transferred to the other handset.

#### **Announced Transfer**

- 1 Follow steps 1 through 3 above.
- 2 To answer the page on the other handset, press OK ( ).
- 3 Tell the person on the other handset that you are transferring a call, then press UNHOLD ( ). The call is transferred to the other handset and all three individuals are on the call.
- 4 Press OFF ( ) to hang up the second handset.

## Using the Handset as a Walkie-Talkie

The walkie-talkie feature lets you talk handset to handset even when the handsets are out of range from the base station. When a handset is in walkie-talkie mode, you cannot make or receive phone calls You must complete steps 1 and 2 for both handsets to use walkie-talkie mode.

- 1 Press MENU ( ).
- 2 Scroll to Walkie-Talkie and press SELECT (<</p>
  ).
- 3 Press Intercom on one of the handsets.
- 4 Press the number on the handset keypad that corresponds to the handset you want to use walkie-talkie with.
  - For example, if the handset you want to talk to is named Kitchen(2), press 2 on the keypad.
- 5 To answer the page on the other handset, press OK ( ).
- 6 To end the walkie-talkie session, press EXIT ( ) on either handset.

# **Monitoring a Room**

Room monitoring allows you to place a handset in a room and listen to the sounds in that room from another handset.

#### **Action**

- Place a handset in the room to be monitored.
- 2 On that handset, press MENU ( ).
- 3 Scroll to Monitor Room and press SELECT (⇐⇒). The display shows Ready to monitor room.
- 4 On the handset you want to listen from, press Intercom. The display lists the handsets registered to the base station.
  - **Note:** If there are only 2 handsets registered to the base, pressing the Intercom button will automatically page the other handset.
- 5 Scroll to the handset you set up monitoring on and press PAGE ( ).

The handset that was set up for monitoring automatically answers the page. The microphone on that handset is turned on, and the speaker is turned off. The handset you are monitoring from shows Monitoring (handset name).

To turn off monitoring, press CANCEL ( ) or OFF on either handset.

**Note:** If you answer an incoming call, monitoring is turned off.

# **Deregistering All Handsets**

**Caution:** You can deregister all handsets from the base station and render your cordless telephone system inoperable until at least one handset is reregistered to the base station (see page 19 for registration information).

**Caution:** Read and perform the following instructions carefully. Missing or performing a step incorrectly renders your cordless telephone system inoperable.

## **Action**

 Delete or listen to all voice mail messages, if necessary, to clear the IN USE/Voice Mail indicator.

**Note:** Skip this step if it does not apply to your MD Series telephone model.

- **2** Press OFF on the base station and all handsets.
- 3 Press and hold down PAGE on the base station until the IN USE indicator begins to flash slowly, then release.
- 4 Press and hold down PAGE again until the IN USE indicator begins to flash quickly, then release PAGE.
- 5 Quickly and fully press and release PAGE again.
- 6 Please register handset displays. Press OK to begin the registration process (see page 19,) or press EXIT.

# Motorola Limited Warranty for the United States and Canada

## What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

## Products and Accessories

<b>Products Covered</b>	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

<b>Products Covered</b>	Length of Coverage
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

#### **Exclusions**

**Normal Wear and Tear.** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries.** Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

**Use of Non-Motorola Products and Accessories.** Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

**Unauthorized Service or Modification.** Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

**Altered Products.** Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

**Communication Services.** Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

#### Software

Products Covered	Length of Coverage
<b>Software.</b> Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

#### **Exclusions**

**Software Embodied in Physical Media.** No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

**Software NOT Embodied in Physical Media.** Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

#### Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

#### What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

# How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456
	Pagers 1-800-548-9954
	Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	<b>All Products</b> 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software, please call the telephone number	

designated above for the product with which they are used.

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

## What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SHALL BE LIMITED TO THE DURATION OF

THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT. OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, IN NO EVENT SHALL MOTOROLA BE LIABLE. WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA. SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

## motorola.com